



1316 Commerce Street, Birmingham, AL 35127
Office: (205) 545 - 8601 Facsimile (205) 841 - 3242
www.protectivecagesllc.com

HVAC CONDENSER GUARD 1500 SERIES ASSEMBLY INSTRUCTIONS

Warning: product may contain sharp edges. Use of personal protective equipment is recommended.

TOOLS REQUIRED: Screw gun with socket adapter

STEP 1: Ensure all parts are included in the package. It will include four panels for an OB1500 model, five panels for a CB1500 model. Eight self drilling screws for attaching the panels together and an additional six for attaching the rear door on CB1500 models are included.

STEP 2: Lay the top panel, "A" label side up on a stable surface. Using the self drilling screws attach the top to side panel "B" using the predrilled holes as guides. The labels should be facing the interior of the cage. A magnetic socket adapter or taping the screw into the socket makes this easier.

STEP 3: Using the supplied self drilling screws attach side panel "C" to panel "A" using the predrilled holes. The labels should be facing the interior of the cage.

STEP 4: Insert the front panel, "D" in between panels "B" and "C". The hinge brackets on "D" should be oriented upwards and the label should face the cages interior. Attach the panels using the supplied self drilling screws using the predrilled holes as guides.

STEP 5: Flip the cage over so the hinges rest on the ground. If the model has a rear door, it can now be installed using six screws by aligning the predrilled holes and inserting the screws. Slide the provided hinge mounting brackets onto the hinge rod which is attached to the bottom of the front panel. Place the cage over the HVAC condenser so it will pivot and cover the unit. Be sure to align the lock holes on the rear brackets with the lock holes on the rear legs of the cage. Mark the selected anchor locations using the holes in the hinge mounting brackets and rear locking brackets. The cage is now ready for installation using the method of your choosing. Due to the various methods and field conditions that may be encountered, anchoring hardware is not included with your shipment.